



Address	Switches								Jumper
	1	2	3	4	5	6	7	8	
1	ON	off	off	off	off	off	off	off	off
2	off	ON	off	off	off	off	off	off	off
3	ON	ON	off	off	off	off	off	off	off
..
116	off	off	ON	off	ON	ON	ON	off	off
..
128	off	off	off	off	off	off	off	off	ON
256	ON	ON	ON	ON	ON	ON	ON	ON	ON

Addresses are set as binary number with switches

If switches are set to address 1, LEDs on the output are controlled with addresses 1,2,3 and 4

To controll completely new light, address on the second controller must be set to 5.

Multiple controllors can be set to the same address to control lights equally.